



# DryRod®II Type 5 with handles Portable Electrode Oven Repair Parts List and Diagram

[CLICK HERE TO PLACE A REPAIR PARTS ORDER](#)

Item No.	Description	Qty/Oven	Part #
			1205521 1205523
1	Divider Kit	1	1257510
2	Insulation	1	1257310
3	Heating Element Kit	1	1257360
Lid Assembly Kit Includes			1257240
4	Lid Assembly	1	
5	Insulation	1	
Latch Kit Includes			1257380
6	Latch	1	
7	Rivet	2	
Variable Thermostat Kit Includes			1257430
8	Variable Thermostat	1	
9	Nut	1	
10	Knob	1	
Preset Thermostat Kit			1257435
11	Preset Thermostat	1	
12	Rivet	2	
Power Inlet Kit Includes			1257390
13	Rivet	2	
14	Locking Power Inlet	1	
Voltage Selector Switch Kit Includes			1257410
15	Rivets	2	
16	120/240V Selector Switch	1	
17	Indicator Light	1	1257400
Thermometer Kit Includes (standard on 1205521 only)			1257420
18	Push-nut	1	
19	Digital Thermometer	1	
20	Screw	2	
21	Label	1	
22	Clamp	1	

Item No.	Description	Qty/Oven	Part #
			1205521 1205523
Jumper Wire Kit Includes			1257532
not shown	Power Wires	8	
	Ground Wire	1	
Power Cord Kit Includes			1257540
not shown	120V North American Locking Cord	1	
Locking Power Connection Kit Includes			1257395
13	Rivet	2	
14	Locking Power Inlet	1	
not shown	120V North American Locking Cord	1	
Lanyard Kit Includes			
35	Lanyard	1	1257537
36	Screws	2	
Handle Kit Includes			1257590
37	Screws	8	
38	Handle	2	
Base Kit Includes			1257580
39	Feet, Rubber	4	
40	Nut	4	
41	Bottom Cover	1	
42	Lock Washer	4	

